




SIM7100_SIM7600M22

Series_TTS_Application Note_V1.02



SIMCOM CONFIDENTIAL FILE

Document Title:	SIM7100_SIM7600M22 Series_TTS_Application Note
Version:	1.02
Date:	2017-09-20
Status:	Release
Document ID:	SIM7100_SIM7600M22 Series_TTS_Application Note_V1.02

General Notes

SIMCom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by SIMCom. The information provided is based upon requirements specifically provided to SIMCom by the customers. SIMCom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of SIMCom Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2017

Version History

Version	Chapter	Comments
V1.00	New Version	
V1.01	2.2 AT+CTTS	Modify parameters of read command and write command
V1.02	2.2 AT+CTTS	Add write command
V1.02	3.6 TTS to wav format	Add TTS to wav format

Contents

Version History	2
Contents	3
1. Introduction	4
1.1 Overview.....	4
2. TTS Related AT Commands	5
2.1 AT+DTAM Set Local or Remote Audio Play	5
2.2 AT+CTTS TTS operation	6
2.3 AT+CTTSPARAM Set TTS Parameters	7
3. TTS Application example	9
3.1 Set Local or Remote Audio Play.....	9
3.2 Play synthetic speech with UCS2 text	10
3.3 Play synthetic speech with normal text.....	10
3.4 Stop the synthetic speech	10
3.5 Set the speech parameters	11
3.6 TTS to wav format	11
Contact Us	12

1. Introduction

1.1 Overview

This document gives the usage of SIM7100/SIM7600CE-A/SIM7600CE-T/SIM7600I TTS functions. User can get useful information about the SIM7100/SIM7600CE-A TTS functions quickly through this document.

The TTS functions are provided in AT command format, and they are designed for customers to design their TTS applications easily. User can access these TTS AT commands through UART/ USB interface which communicates with SIM7100/SIM7600CE-A/SIM7600CE-T/SIM7600I module. Now Chinese and English languages can be supported.

2. TTS Related AT Commands

Below is the TTS associated with AT commands. Related.

Command	Description
AT+CDTAM	Set TTS Play Path
AT+CTTS	TTS operation
AT+CTTSPARAM	Set TTS parameters

2.1 AT+DTAM Set Local or Remote Audio Play

AT+CDTAM Set TTS Play Path	
Test Command AT+CDTAM=?	Response +CDTAM: (0-1) OK
	No parameter
Read Command AT+ CDTAM?	Response + CDTAM: <status> OK
	Parameter <status> 0 Local Path 1 Remote Path
Write Command AT+CDTAM=< mode>	Response +CDTAM: OK
	Parameter < mode > 0 Local Path 1 Remote Path
Reference	Note

2.2 AT+CTTS TTS operation

AT+CTTS TTS Operation	
Test Command AT+CTTS=?	Response
	OK
	No parameter
Read Command AT+CTTS?	Response
	+CTTS: <status>
	OK
	Parameter
	<status>
	0 Idle status
	5 Play status
Write Command AT+CTTS=<mode>,<text>	Response
	If <mode>is 0, return: +CTTS: OK
	If <mode>is 1 or 2, return: +CTTS: OK
	+CTTS:0 //speech synth and play end
	Note: AT+CTTS? return value is 5 before the end of voice play (+ CTTS: 0)
	If error is related to MS functionality,response: +CME ERROR: <err>
	Parameter
	<mode>
	0 Stop the speech synth and play
	1 Start to synth and play, <text> is in UCS2 coding format.
	2 Start to synth and play, <text> is in ASCII coding format, Chinese text is in GBK coding format
	<text> The text which is synthesized to speed to be played,maximum data length is 512 bytes. (including "")

<p>Write Command AT+CTTS=<mode>,<text>,<filename></p>	<p>Response</p> <p>If <mode>is 3, return: +CTTS: OK</p> <p>+CTTS:0 // transform end</p> <p>If <mode>is 4, return: +CTTS: OK</p> <p>+CTTS:0 // transform end</p> <p>+CME ERROR: <err></p>
	<p>Parameter</p> <p><mode></p> <ul style="list-style-type: none"> 0 TTS To wav format, <text> is in ASCII coding format, Chinese text is in GBK coding format 1 TTS To wav format, <text> is in UCS2 coding format. <p><text> The text which is transformed to wav format,maximum data length is 512 bytes. (including "")</p> <p><filename> Saved location and name. The file should be put into the "E:/filename.wav".</p>
Reference	Note

2.3 AT+CTTSPARAM Set TTS Parameters

AT+CTTSPARAM Set TTS Parameters	
<p>Test Command AT+CTTSPARAM=?</p>	<p>Response</p> <p>+CTTSPARAM: (0-2),(0-3),(0-3),(0-2),(0-2)</p> <p>OK</p> <p>No parameter</p>
<p>Read Command AT+CTTSPARAM?</p>	<p>Response</p> <p>+CTTS: <volume>,<sysvolume>,<digitmode>,<pitch>,<speed></p> <p>OK</p>

<p>Write Command AT+ CTTSPARAM =<volume>[,<sysvolume>[,<digitmode>[,<pitch>[,<speed>]]]]</p>	<p>Response</p> <p>OK</p> <p>If error is related to MS functionality,response: +CME ERROR: <err></p> <p>Parameter</p> <p><volume> TTS Speech Volume, 0-2 0 The mix volume 1 The normal volume 2 The max volume</p> <p>< sysvolume> The module system volume, 0-3 0 The mix system volume 1 The small system volume 2 The normal system volume 3 The max system volume</p> <p><digitmode> The digit read mode 0-3 0 Auto read digit based on number rule first. 1 Auto read digit bases on telegram rule first. 2 Read digit based on telegram rule. 3 Read digit based on number rule.</p> <p><pitch> The voice tone 0-2 0 The mix voice tone. 1 The normal voice tone. 2 The max voice tone.</p> <p><speed> The voice speed 0-2 0 The mix speed 1 The normal speed 2 The max speed</p>
<p>Reference</p>	<p>Note</p>

3. TTS Application example

Below is the TTS associated with application examples

3.1 Set Local or Remote Audio Play

```
AT+ CDTAM =1                //Set Remote Path
+CDTAM:
```

OK

AT+ CDTAM =0 //Set Local Path
+CDTAM:

OK

3.2 Play synthetic speech with UCS2 text

AT+CTTS=1,"6B228FCE4F7F75288BED97F3540862107CFB7EDF" //note:txt UCS2 coding
+CTTS: format.

OK

+CTTS:0

//note:speech synthetic
successful, the tts voice
will play with the
current channel.

//note:Speech played
over;User need s to
waiting this response to
play the next speech!

3.3 Play synthetic speech with normal text

AT+CTTS=2,"hello, 欢迎使用语音合成系统"
+CTTS:

OK

+CTTS:0

//note:txt ASIIIC coding
format, chinese is GBK
coding format.

//note:speech synthetic
successful, the tts voice
will play with the
current channel.

//note:Speech played
over;User need s to
waiting this response to
play the next speech!

3.4 Stop the synthetic speech

AT+CTTS=0
+CTTS:

//note:stop playing
synthetic speech.

//note:synthetic

OK

speech.is successful end

3.5 Set the speech parameters

AT+CTTSPARAM=1,3,0,1,1

//note:set the speech parameters

OK

//note:set the successful for parameter.

3.6 TTS to wav format

AT+CTTS=3,"欢迎使用语音合成系统","E:/tts.wav"

//note:txt ASIIC coding format, chinese is GBK coding format.

+CTTS:

OK

//note: transform end

+CTTS:0

Contact Us

Shanghai SIMCom Wireless Solutions Ltd.

Add: Building A, SIM Technology Building, No.633, Jinzhong Road, Changning District
200335

Tel: +86 21 3252 3300

Fax: +86 21 3252 3301

URL: <http://www.sim.com/wm/>

SIMCOM CONFIDENTIAL FILE