


Power Flash Simcom user guide




Firmware Update

To update the SIM28x and SIM68x module software, the following operations are needed:


1. Install the tool of “Power Flash”.
2. Connect the module to PC with UART 3.0V \leftrightarrow USB cable.

Step 1. Open the tool Power Flash, the following figure shows the interface of power flash.


Step 2. Using the combination key “CTRL+ALT+T” to set the port, the password is “123456”.




Step 3. The window UI has changed.



Step 4. Setting the number of comport as following figure shows.




Step 5. Setting the update baudrate as 460800.




Step 6. Load files to the power flash.


Download Agent: the file as example - B03V11SIM68M_96_AllInOne_DA_MT3333_3_MP.BIN
 Download ROM: the file as example - B03V11SIM68M_96.bin;



Step 7. The DA file is in downloading proceeding.



Step 8.The ROM is in downloading proceeding.



Step 9.Firmware update succeeds.

