



## **SIM7000** Series\_MQTT\_Application Note

Version:1.00

Release Date:Aug 07, 2018

# About Document

## Document Information

Document	
Title	SIM7000 Series_MQTT_Application Note
Version	1.00
Document Type	Application Note
Document Status	Released/Confidential

## Revision History

Revision	Date	Owner	Status / Comments
1.00	Aug 07, 2018	Xiaobao.qu	First Release.

## Related Documents

[1] SIM7000 Series AT Command Manual V1.03.pdf

### This document applies to the following products:

Name	Type	Size (mm)	Comments
SIM7000E/C/A/G	Cat-M1 (/NBI/ GSM)	24*24	N/A
SIM7000E-N	NBI	24*24	N/A
SIM7000C-N			

## Copyrights

This document contains proprietary technical information which is the property of SIMCom Wireless. Copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

# Contents

<b>About Document .....</b>	<b>2</b>
Document Information.....	2
Revision History.....	2
Related Documents .....	2
<b>Contents.....</b>	<b>3</b>
<b>1 Purpose of this document .....</b>	<b>4</b>
<b>2 AT Commands for MQTT .....</b>	<b>4</b>
2.1 Overview .....	4
2.2 Detailed Descriptions of Commands.....	4
2.2.1 AT+SMCONF Set MQTTParameter.....	4
2.2.2 AT+CSSLCFG SSL Configure .....	6
2.2.3 AT+SMSSL Select SSL Configure.....	6
2.2.4 AT+SMCONN MQTT Connection .....	7
2.2.5 AT+SMPUB Send Packet .....	7
2.2.6 AT+SMSUB Subscribe Packet .....	7
2.2.7 AT+SMUNSUB Unsubscribe Packet.....	8
2.2.8 AT+SMSTATE Inquire MQTT Connection Status.....	8
2.2.9 AT+SMPUBHEX Set SMPUB Data Format to Hex .....	9
2.2.10 AT+SMDISC Disconnect MQTT .....	9
<b>3 Bearer Configuration .....</b>	<b>9</b>
3.1 PDN Auto-activation.....	10
3.2 MQTT Function.....	10
3.3 MQTTS Function.....	11
<b>Contact.....</b>	<b>12</b>

# 1 Purpose of this document

Based on module AT command manual, this document will introduce MQTT application process.

Developers could understand and develop application quickly and efficiently based on this document.

## 2 AT Commands for MQTT

### 2.1 Overview

Command	Description
AT+SMCONF	Set MQTT Parameter
AT+CSSLCFG	SSL Configure
AT+SMSSL	Select SSL Configure
AT+SMCONN	MQTT Connection
AT+SMPUB	Send Packet
AT+SMSUB	Subscribe Packet
AT+SMUNSUB	Unsubscribe Packet
AT+SMSTATE	Inquire MQTT Connection Status
AT+SMPUBHEX	Set SMPUB Data Format to Hex
AT+SMDISC	Disconnection MQTT

### 2.2 Detailed Descriptions of Commands

#### 2.2.1 AT+SMCONF Set MQTTParameter

AT+SMCONF Set MQTT Parameter	
Test Command AT+SMCONF=?	Response +SMCONF: "MQTTParamTag", "MQTTParamValue range"  OK

<p>Read Command <b>AT+SMCONF?</b></p>	<p>Response <b>+SMCONF: &lt;MQTTParamTag&gt;,&lt;MQTTParamValue&gt;</b></p> <p><b>OK</b></p>
<p>Write Command <b>AT+SMCONF=&lt;MQTTParamTag&gt;,&lt;MQTTParamValue&gt;</b></p>	<p>Response <b>OK</b> or <b>ERROR</b></p> <p>Parameters <b>&lt;MQTTParamTag&gt;</b>  <b>"CLIENTID"</b> Client connection id  <b>"URL"</b> (indispensable parameter) server URL address  <u>"server domain",["tcpPort"]</u>  "server": Host or IP  "tcpPort": Port default is 1883  <b>"KEEPTIME"</b> Hold connect time. default is 60s  <b>"CLEANSS"</b> Session cleanin. Default is 0.  Range of values:(0-1).  <b>"USERNAME"</b> User name. default null  <b>"PASSWORD"</b> Password. default null  <b>"QOS"</b> Send packet qos level. range of values (0~2)  <b>"TOPIC"</b> Publish topic name  <b>"MESSAGE"</b> Publish message details  <b>"RETAIN"</b> Retain identification. Default is 0.  Range of values:(0-1)  <b>&lt;MQTTParamValue&gt;</b> MQTT Parameter value. Type and supported content depend on related <b>&lt;MQTTParamTag&gt;</b>.</p>
<p>Example</p>	<pre>AT+SMCONF="CLIENTID","id" OK AT+SMCONF="KEEPTIME",60 OK AT+SMCONF="URL","test.mosquitto.org","1883" OK AT+SMCONF="CLEANSS",1 OK AT+SMCONF="QOS",1 OK AT+SMCONF="TOPIC","will topic" OK AT+SMCONF="MESSAGE","will message" OK AT+SMCONF="RETAIN",1 OK</pre>

## 2.2.2 AT+CSSLCFG SSL Configure

AT+CSSLCFG SSL Configure	
Write command <b>AT+CSSLCFG="convert", &lt;ssltype&gt;,&lt;cname&gt;,[&lt;keyname&gt;],[&lt;passkey&gt;]]</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;ssltype&gt;</b> 1 QAPI_NET_SSL_CERTIFICATE_E 2 QAPI_NET_SSL_CA_LIST_E 3 QAPI_NET_SSL_PSK_TABLE_E <b>&lt;cname&gt;</b> String type(string should be included in quotation marks): name of cert file <b>&lt;keyname&gt;</b> String type(string should be included in quotation marks):name of key file <b>&lt;passkey&gt;</b> String type (string should be included in quotation marks):value of passkey
Parameter Saving Mode	-
Max Response Time	-
Reference	-

## 2.2.3 AT+SMSSL Select SSL Configure

AT+SMSSL Select SSL Configure	
Read Command <b>AT+SMSSL?</b>	Response <b>+SMSSL: &lt;index&gt;,&lt;ca list&gt;,&lt;cert name&gt;</b>  <b>OK</b>
Write Command <b>AT+SMSSL=&lt;index&gt;,&lt;ca list&gt;,&lt;cert name&gt;</b>	Response <b>OK</b> or <b>ERROR</b>
	Parameters <b>&lt;index&gt;</b> SSL status,range: 0-6 <b>&lt;ca list&gt;</b> CA_LIST file name,length 20 byte <b>&lt;cert name&gt;</b> CERT_NAME file name,length 20 byte
Example	AT+SMSSL=1,calist,certname OK

## 2.2.4 AT+SMCONN MQTT Connection

AT+SMCONN MQTT Connection	
Executive Command <b>AT+SMCONN</b>	Response <b>OK</b> or <b>ERROR</b>
Example	AT+SMCONN OK

## 2.2.5 AT+SMPUB Send Packet

AT+SMPUB Send Packet	
Test Command <b>AT+SMPUB=?</b>	Response <b>+SMPUB: &lt;topic&gt;,&lt;content length&gt;,(0-2),(0-1)</b>  <b>OK</b>
Write Command <b>AT+SMPUB=&lt;topic&gt;,&lt;content length&gt;,&lt;qos&gt;,&lt;retain&gt;</b>	Response <b>OK</b> or <b>ERROR</b>  Parameters <topic>Subscribe packet <qos>Send packet QOS level, range: 0~2 <content length>Message length, range: 0~512 <retain>Server hold message range: 0~1
Example	AT+SMPUB="001",10,1, 1 OK

## 2.2.6 AT+SMSUB Subscribe Packet

AT+SMSUB Subscribe Packet	
Test Command <b>AT+SMSUB=?</b>	Response <b>+SMSUB: "topic",qos</b>  <b>OK</b>
Write Command <b>AT+SMSUB=&lt;topic&gt;,&lt;qos&gt;</b>	Response <b>OK</b> or <b>ERROR</b>

	<p>Parameters</p> <p>&lt;topic&gt;Subscribe packet</p> <p>&lt;qos&gt;Send packet qos level, range: 0~2</p>
Example	<p>AT+SMSUB="001",1</p> <p>OK</p>

## 2.2.7 AT+SMUNSUB Unsubscribe Packet

AT+SMUNSUB Unsubscribe Packet	
<p>Read Command</p> <p><b>AT+SMUNSUB=?</b></p>	<p>Response</p> <p><b>+SMUNSUB: "topic"</b></p> <p><b>OK</b></p>
<p>Write Command</p> <p><b>AT+SMUNSUB=&lt;topic&gt;</b></p>	<p>Response</p> <p><b>OK</b></p> <p>or</p> <p><b>ERROR</b></p>
	<p>Parameters</p> <p>&lt;topic&gt; Subscribe subject</p>
Example	<p>AT+SMUNSUB="001"</p> <p>OK</p>

## 2.2.8 AT+SMSTATE Inquire MQTT Connection Status

AT+SMSTATE Inquire MQTT Connection Status	
<p>Read Command</p> <p><b>AT+SMSTATE?</b></p>	<p>Response</p> <p><b>+SMSTATE: &lt;status&gt;</b></p> <p><b>OK</b></p>
	<p>Parameters</p> <p>&lt;status&gt;</p> <p>0 Expression MQTT disconnect state</p> <p>1 Expression MQTT on-line state</p>
Example	<p>AT+SMSTATE?</p> <p>+SMSTATE: 1</p> <p>OK</p>



## 2.2.9 AT+SMPUBHEX Set SMPUB Data Format to Hex

AT+SMPUBHEX Set SMPUB Data Format to Hex	
Test Command <b>AT+SMPUBHEX=?</b>	Response <b>+SMPUBHEX: (0-1)</b>  <b>OK</b>
Read Command <b>AT+ SMPUBHEX?</b>	Response <b>+SMPUBHEX: &lt;status&gt;</b>  <b>OK</b>  PARAMETERS <b>&lt;status&gt;</b> 0 SMPUB data format is normal 1 SMPUB data format is hex
Write Command <b>AT+SMPUBHEX=&lt;status&gt;</b>	Response <b>OK</b> or <b>ERROR</b>  Parameters <b>&lt;status&gt;</b> SMPUB format status, range: 0~1
Example	AT+SMPUBHEX=1  OK

## 2.2.10 AT+SMDISC Disconnect MQTT

AT+SMDISC Disconnect MQTT	
Executive Command <b>AT+SMDISC</b>	Response <b>OK</b> or <b>ERROR</b>
Example	AT+SMDISC  OK

# 3 Bearer Configuration

Usually module will register PS service automatically.

## 3.1 PDN Auto-activation

AT Command	Response	Description
AT+CPIN?	+CPIN:READY  OK	Check SIM card status
AT+CSQ	+CSQ: 20,0  OK	Check RF signal
AT+CGREG?	+CGREG: 0,1  OK	Check PS service
AT+COPS?	+COPS: 0,0,"460 01",9  OK	Query Network information, operator and network mode 9, NB-IOT network
AT+CGNAPN	+CGNAPN: 1,"ctnb"  OK	Query CAT-M or NB-IOT network after the successful registration of APN

## 3.2 MQTT Function

AT Command	Response	Description
AT+CNACT=1,"cmnet"	OK  +APP PDP: ACTIVE	Open wireless connection parameter CMNET is APN, this parameter needs to set different APN values according to different cards
AT+CNACT?	+CNACT: 1,"10.181.182.177"  OK	Get local IP
AT+SMCONF="URL",117.131.85.139,6000	OK	Set up server URL
AT+SMCONF="KEEPTIME",60	OK	Set MQTT time to connect server
AT+SMCONN	OK	
AT+SMSUB="update",1	OK	Subscription packet
AT+SMPUB="update",5,1,1 >hello	OK  +SMSUB: "update","hello"	Send packet  Get data on server
AT+SMUNSUB="update"	OK	Unsubscription packet
AT+SMDISC	OK	Disconnect MQTT
AT+CNACT=0	OK	Disconnect wireless

+APP PDP: DEACTIVE

### 3.3 MQTTS Function

AT Command	Response	Description
AT+CNACT=1,"cmnet"	OK  +APP PDP: ACTIVE	Open wireless connection parameter CMNET is APN, this parameter needs to set different APN values according to different cards
AT+CNACT?	+CNACT: 1,"10.181.182.177"  OK	Get local IP
AT+SMCONF="URL",117.131. 85.139,6001	OK	Set up server URL
AT+SMCONF="KEEPTIME",60	OK	Set MQTT time to connect server
AT+CSSLCFG=convert,2,ca.crt	OK	rootCA.pem is ca certificate
AT+CSSLCFG=convert,1,mycli ent.crt,myclient.key	OK	cert.pem is certificate, key.pem is key of cert.pem
AT+SMSSL=1,ca.crt,myclient. crt	OK	Set ca certificate and cert certificate name
AT+SMCONN	OK	
AT+SMSUB="update",1	OK	Subscription packet
AT+SMPUB="update","5",1,1 >hello	OK  +SMSUB: "update","hello"	Send packet  Get data on server
AT+SMUNSUB="update"	OK	Unsubscription packet
AT+SMDISC	OK	Disconnect MQTT
AT+CNACT=0	OK  +APP PDP: DEACTIVE	Disconnect wireless

# Contact

## Shanghai SIMCom Wireless Solutions Ltd.

Address: Building B, No.633 Jinzhong Road, Changning District, Shanghai P.R.China 200335

Tel: +86 21 3157 5100, +86 21 31575 5200

Email: [simcom@simcom.com](mailto:simcom@simcom.com), [simcom@sim.com](mailto:simcom@sim.com)

Website: [www.simcomm2m.com](http://www.simcomm2m.com)

## Technical Support

Email: [support@simcom.com](mailto:support@simcom.com)